

# Start and Control Speed from HIM

## Program:

**File - (Speed Command)**

**Group - Speed Reference**

90 (Speed Reference) = 18

**File - Digital Inputs**

**Group - Inputs & Outputs**

361 (Digital In1 Sel) = 0

362 (Digital In2 Sel) = 0

363 (Digital In3 Sel) = 10

364 (Digital In4 Sel) = 15

365 (Digital In5 Sel) = 16

366 (Digital In6 Sel) = 17