

Revision	v4.02			v5.02		v1.01	v1.02	v4.04
	DriveExecutive Lite	DriveExecutive	DriveObserver	DriveExplorer	DriveExplorer Lite	Pocket DriveExplorer for Pocket PC	Pocket DriveExplorer for Windows CE	
<b>Operating Systems</b>								
Windows 95								
Windows 98/ME								
Windows NT	√	√	√	√	√			
Windows 2000/XP	√	√	√	√	√			
Windows Mobile 2003 / Second Edition						√		
Windows Mobile 5.0							√	
Windows CE 3.0 on VersaView CE								√
Windows CE 4.1 on VersaView CE								√
Windows CE (Handheld PCs:SH3 or SH4 processor running Windows 2.11 or Strong ARM processor running Windows CE 2.11 or 3.0)								√
<b>Software Availability</b>								
Sold Separately		√		√		√	√	√
Freeware				√				
Included in DriveTools SP software suite		√	√					
Included with RSLogix 5000 Std / Pro	√							
Included with RSNetworx MD	√							
<b>Integration</b>								
Integrated with RSLogix 5000 Std, Full, Pro	√	√						
Integrated with RSNetworx MD	√	√						
Integration with VersaView CE								√
<b>DPI (PowerFlex 70, 700, 700S and SMC-FLEX)</b>								
Serial point-to-point using 1203-SSS or 1203-USB		√		√	√	√	√	√
Serial to ControlNet, DeviceNet, Ethernet, RS485 network via 1203-SSS, 1203-USB, 1203-GU6, or 1203-CN1 adapter				√		√	√	√
Serial to DeviceNet via 1771-KFD	Not recommended							
Serial to ControlNet via 1771-KFC		√						
Serial modem point-to-point		√						
DeviceNet direct		√						
ControlNet direct		√						
EtherNet/IP direct		√		√		Wi-Fi	Wi-Fi	√
Wireless Interface Module (WIM) connectivity		√		√	√	√	√	
DH+ direct		√						
RSLinx gateways		√						
ControlLogix backplanes / RSLinx shortcuts		√						
Ethernet to CompactLogix backplane to 1769-SM1		√						

Revision	DriveExecutive Lite		DriveExecutive		DriveObserver		DriveExplorer		DriveExplorer Lite		Pocket DriveExplorer for Pocket PC		Pocket DriveExplorer for Windows CE		
	v4.02		v5.02		v1.01	v1.02	v4.04		v1.01	v1.02	v4.04		v1.01	v1.02	v4.04
<b>DSI (PowerFlex 4, 40, 400)</b>															
Serial point-to-point using 22-SCM-232 or 1203-USB	√		√	√	√	√	√		√	√	√				
Serial modem point-to-point	√														
DeviceNet direct	√														
EtherNet/IP direct	√		√						Wi-Fi	Wi-Fi	√				
Multi-drive	√		√						√	√	√				
Wireless Interface Module (WIM) connectivity	√		√	√					√	√					
RSLinx gateways	√														
ControlLogix backplanes / RSLinx shortcuts	√														
Ethernet to CompactLogix backplane to 1769-SM2	√														
<b>SCANport (1336 PLUS II, 1336 IMPACT, etc.)</b>															
Serial point-to-point using 1203-SSS or 1203-USB	√		√	√	√	√	√		√	√	√				
Serial point-to-point using 1203-GD2, 1203-GK2	√		√	√											√
Serial point-to-point using 1203-GU6, 1203-CN1, 1203-EN1 via DF1 port	√		√	√	√	√	√		√	√	√				√
Serial to ControlNet, DeviceNet, Ethernet, RS485 network via 1203-SSS or 1203-USB			√												√
Serial to ControlNet, DeviceNet, EtherNet/IP network via 1203-GU6, 1203-CN1, 1203-EN1 adapter			√												√
Serial to DeviceNet via 1771-KFD	Not recommended														
Serial to ControlNet via 1771-KFC	√														
Serial modem point-to-point	√														
DeviceNet direct	√														
ControlNet direct	√														
EtherNet/IP direct	√		√						Wi-Fi	Wi-Fi	√				
DH+ direct	√														
RSLinx gateways	√														
ControlLogix backplanes direct	√														
RSLinx shortcuts	√														
Wireless Interface Module (WIM) connectivity	√		√	√	√	√	√		√	√					
<b>Bulletin 160 Drives</b>															
Serial via RS1	√		√	√											√
<b>1395 Digital DC Drives</b>															
Direct Serial or USB-to-Serial	√														
ControlNet/DH+	√														

Revision	DriveExecutive Lite			DriveExecutive			DriveObserver			DriveExplorer			DriveExplorer Lite			Pocket DriveExplorer for Pocket PC			Pocket DriveExplorer for Windows CE		
	v4.02			v5.02			v1.01	v1.02	v4.04												
<b>Passwords</b>																					
HIM password support				√	√		√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
<b>Offline Editing</b>																					
Parameter Editing/Viewing in drive	√	√																			
Link Editing/Viewing in drive	√	√																			
Parameter Editing/Viewing in adapter	√	√																			
Link Editing/Viewing in adapter	√	√																			
Offline viewing of saved charts			√																		
<b>Online Editing</b>																					
Parameter Editing/Viewing in drive	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Link Editing/Viewing in drive	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Parameter Editing/Viewing in adapter	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Link Editing/Viewing in adapter	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Security Awareness		√		√	√																
Online collection of charted data			√																		
<b>File Saving</b>																					
Save/restore drive parameters to/from PC	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Save/restore drive links to/from PC	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Save/restore adapter parameters to/from PC	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Save/restore adapter links to/from PC	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Files embed all data that any user can open offline	√	√																			
Download only selected parameters				√	√																√
Folder Upload / Download (entire group of drives)		√																			
Save/restore configuration objects (inc. HIM CopyCat)				√	√		√	√		√	√		√	√		√	√		√	√	
<b>Setup Aids</b>																					
Wizards	√	√		√	√		√	√													
Datalink setup view	√	√																			
Functional diagram views		√																			
Custom groups	√	√																			
Custom views from multiple drives / peripherals				√	√		√	√													√
Start & Stop Control		√		√	√		√	√		√	√		√	√		√	√		√	√	
To/from DriveLogix setup	√	√																			
SynchLink setup	√	√																			
<b>Diagnostic Aids</b>																					
Diagnostic Item Editing/Viewing		√		√	√		√	√		√	√		√	√		√	√		√	√	
Fault/Alarm Viewing and Management	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Event Viewing and Management	√	√		√	√		√	√		√	√		√	√		√	√		√	√	
Search on Parameter #		√	√	√	√		√	√													√
Search on Parameter Name		√	√	√	√																
Search on Parameter Units		√																			

Revision	v4.02		v5.02		v1.01	v1.02	v4.04
<b>Compares</b>							
Compares Compare Parameters Online to Default	✓	✓	✓	✓			✓
Compare Links Online to Default	✓	✓	✓	✓			✓
Compare Parameters Online to File	✓	✓	✓	✓			✓
Compare Links Online to File	✓	✓	✓	✓			✓
Compare Parameters Online to Online	✓	✓					
Compare Links Online to Online	✓	✓					
Compare Parameters File to File	✓	✓	✓	✓			✓
Compare Links File to File	✓	✓	✓	✓			✓
Compare Parameters File to Default	✓	✓					
Compare Links File to Default	✓	✓					
Make the two compared things the same	✓	✓					
Compare parameter names	✓	✓					
Compare parameter min/max/default	✓	✓					
Compare linear list	✓	✓	✓	✓			✓
Compare groups	✓	✓					
Compare two different device types	✓	✓					
<b>Maintenance Aids</b>							
Flash update	✓	✓	✓	✓	✓	✓	✓
Web Updates page for product data	✓	✓	✓	✓	✓	✓	✓
<b>Conveniences</b>							
Launching from 20-COMM-E adapter	✓	✓	✓	✓			✓
Drive/adapter specific parameter help	✓	✓	✓	✓			
Drive/adapter specific fault/diagnostic help	✓	✓	✓	✓			
List Most Recent Files in Files menu	✓	✓					
List Most Recent Connections in menu	✓	✓			✓	✓	
Save shortcuts on desktop/file for reconnecting		✓			✓	✓	
<b>Charting Data Types</b>							
Plot parameters in drives		✓					
Plot parameters in adapters		✓					
<b>General Chart</b>							
Traces from different drives on same chart		✓					
Multi-trace selection		✓					
Parameter help		✓					
Ability to open files offline		✓					
Ability to open files and collect new data		✓					
Files embed all data that any user can open		✓					
<b>RSMACC Change Management</b>							
Upload and Upload & Compare functions		✓					