

1334 575V 15-50 HP Parts List

Description	Identification	Part No.	Value	Used On
Modulator Board	550387-001	50387-001	N/A	15-50 HP
Driver/MOPC	119439-2	120576	N/A	15 HP
Interface Board		12057	N/A	20 HP
		120578	N/A	25 HP
		120579	N/A	30 HP
		119440	N/A	40 HP
		118833	N/A	50 HP
Base Driver Board	117410-2	120547	N/A	15-25 HP
		120549	N/A	30-50 HP
High Volt Sensing	118853-2	118853	N/A	15-50 HP
Logic Power Supply	550389	50389	N/A	15-50 HP
Diagnostic Board	550382	50382	N/A	15-50 HP
Ground Sense Board	550385	50385	N/A	15-50 HP
Contactorm Interface	550404-001	50404-001	N/A	15-50 HP
LEM/MOPC Interface	118834-7	118834	N/A	15-50 HP
Input Fuse	1FU,2FU,3FU	112029	35A/600V (JJS 35)	15 HP
		112030	45A/600V (JJS 45)	20 HP
		112031	60A/600V (JJS 60)	25 HP
		112036	80A/600V (JJS 80)	30 HP
		112032	100A,600V (JJS 100)	40 HP
		200175	125A/600V (JJS 125)	50 HP
Fuse	4FU	201590	1A/500V (FNQ 1)	15-50 HP
Fuse	5FU	201708	1.5A/500V (FNQ 1.5)	15-50 HP
	7FU	201478	2/10A/500V (FNQ 2/10)	15-50 HP

Description	Identification	Part No.	Value	Used On
Bus Capacitor	2C1-2C3,3C1-3C3	502637	3300uF/350V	15-25 HP
	4C1-4C3	120593	9000uF/350V	30-50 HP
24V Power Supply	IPS	120553	N/A	15-50 HP
Control Transformer	1T	92402	N/A	15-50 HP
Control Transformer	2T	92404	N/A	15-50 HP
Transformer	3T	92403	N/A	15-50 HP
Current Transformer	1CT	91824	N/A	15-50 HP
MOV Assembly	1MOV	115547	N/A	15-50 HP
Input Inductor	1L1,1L2	120594	N/A	15-25 HP
		91874	N/A	30-50 HP
Inductor	2L	91849	N/A	15-50 HP
		120592	N/A	15-25 HP
Output Inductor	3L,4L,5L	90401	N/A	30-50 HP
Switching Modules	1Q,2Q,3Q	120604	N/A	15-25 HP
		120604	N/A	30-50 HP
Snubber Assembly	SP1,SP2,SP3	119515	N/A	15-50 HP
		120607	N/A	30-50 HP
Temperature Sensor	1 TAS	110447	N/A	15-50 HP
Rectifier Assembly	1REC,2REC,3REC	120514	N/A	15-50 HP
Precharge Contactor	1CON	120520	N/A	15-25 HP
		201459	N/A	15-25 HP
Resistor	1R1,1R2	243426	25 OHM/50W	15-50 HP
Resistor	1R1,1R2	120512	4K OHM/50W	15-25 HP
		120595	2.5K OHM/50W	30-50 HP
Fan	1FN	201508	N/A	30-50 HP