

1341 Parts List

<u>Bare Board</u>	<u>PCB ASSY</u>	<u>PCB KIT</u>	<u>Description / Remark</u>
--	118834	126524	LEM/MOP PCB (INCL WITH HEATSINK KIT)
--	123905	126625	NODE ADAPTER PCB
124002	124003	126524	BASE DRIVER PCB (INCL WITH HEATSINK KIT)
124004	124004	126515	MAIN CONTROL PCB (KELVAR)
124004	124005	129690	MAIN CONTROL PCB (MAITLAND)
124006	124007	126517	DC-DC CONVERTER PCB
124004	128996	129200	MAIN CONTROL PCB (SEAFORD 10 AMP)
124004	129000	129202	MAIN CONTROL PCB (SEAFORD 50 AMP)
126716	126717	128989	POWER SUPPLY PCB 80 W 300/600 V
135535	135546	506448	RIDE THRU - CONTROL PCB
129025	129024	129204	CONTROL BOARD, INTERFACE (SEAFORD - 50 AMP)
119715	119454	124090	SERIAL RS-422