

1386 Parts List

<u>Catalog Number</u>	<u>Part #</u>	<u>Description</u>
<i>drive components:</i>		
1386-M2	135608	2 axis chassis module/power supply
1386-M4	135609	4 axis chassis module/power supply
1386-M4-SPL	*****	Must be ordered with 1386-T050DT-SPL
1386-M6	135610	6 axis chassis module/power supply
1386-AA06	135606	6 amp continuous/15 peak servo amp
1386-AA15	135607	15 amp continuous/30 peak servo amp
1386-K-DROK	133799	Drive O.K. contact board kit
*****	133666	Shunt regulator kit, SR1
*****	119654	TB 1, 6 position terminal block
*****	126604	TB 2, 7 position terminal block
*****	111224	J1 on amplifier board and also J2 on DROK board, conn., 3-pos.
<i>transformers:</i>		
1386-T015PT	140072	1.5kVA, 120/240v primary, 1-ph, 60Hz, 78v secondary
1386-T015PV	151044	1.5kVA, 50/60Hz, 110,120,220,240v primary, 78v secondary
1386-T030DT	140073	3.0kVA, 240/480v primary, 3-ph, 60Hz, 78v secondary
1386-T030VT	*****	3.0kVA, 208/380v primary, 78v secondary, 3-ph
1386-T050DT	140074	5.0kVA, 240/480v primary, 3-ph., 60Hz, 78v secondary
1386-T050DT-SPL	*****	Must be ordered with 1386-M4-SPL