


3 Wire SNK Control Reversing



Parameters that need to be reprogrammed

P036 [Start Source] = 1