

3 Wire SRC Control Non Reversing - Internal Supply

Parameters that need to be reprogrammed

P036 [Start Source] = 1

